



Stain Remover Pen Set of 2



Thank you for purchasing our Stain Remover Pen Set of 2 perfect for erasing of stains such as coffee, tea, red wine, fruit juice, yoghurt, gravy, oil, makeup and more!

We hope you are happy with your purchase.

Features:

- Safe to use on white and coloured clothing
- Safe to use on most fabrics, even some dry clean only items. If you're unsure about using it on certain fabrics, test it on a hidden portion of fabric before use
- Effective on most stains
- Easy to take on the go
- No messes or spills
- Works best on fresh, smaller sized stains

Instructions for use:

- Before starting it is recommended to test the pen on a hidden portion of fabric to make sure the fabric of your garment will not react negatively to the solution.
- Then, gently dab or wipe off any excess residue, like a thick sauce or crumbly food item. Take care not to spread the stain any wider than it already is while doing so.
- Take the cap off and press the tip onto the area of fabric where your stain is located, until enough solution comes out to cover the area of your stain.
- Rub until you see the stain begin to lighten or disappear altogether. Make sure you are getting solution and rubbing with the tip over all areas of the stain.
- Add more solution, if necessary, by depressing the tip again. Each part of the stained fabric should be lightly saturated with solution before rubbing.
- Wait and allow the fabric to dry to determine the success of the stain removal.
- Repeat the process of releasing the solution and rubbing with the pen tip if the stain is still very visible.
- When you are happy that the stain has been removed, blot away any excess solution

N.B The product works best on spills from food and drink. It will not perform well or at all on stains from materials like blood, grease, ink or grass

After use:

The product is formulated for stains that have recently occurred and is used to pretreat a stain quickly before it can be washed. Further laundering is expected.

After treatment, the stain on your garment may still appear slightly discoloured, show faint residue from the solution or have a slight odour. These will all be typically removed with further laundering

- Wash the item according to the care tag instructions. Pay attention to the instructions given on care for your specific garment's fabric and style. Wash by hand, machine, or dry cleaning as instructed.
- Dry the garment carefully. Follow the care instructions for your clothing after washing it, taking care not to apply heat from a dryer or iron until the stain is out. If there is, treat it again with a stain remover and rewash. Don't put it in a dryer until the stain is out, otherwise the heat will set it in.

Caution:



GHS05

•**Hazard-determining components of labelling:** Alcohols, C9-11, Ethoxylated.

•**Hazard statements:**

- H318 Causes serious eye damage
- P101 If medical advice is needed, have product container or label at hand.
- P102 Keep out of reach of children. This is not a toy
- P103 Read carefully and follow all instructions.
- P280 Wear eye protection/ face protection.
- P305+P351+P338+P310 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.
- Always wipe the pen tip or rinse with water after use.
- Store in a cool, dry and ventilated place (under 40 degrees C) out of sunlight.
- Contains bleaching agent, keep clothing and fabrics out of sunlight after use, before washing.
- Do not swallow, if accidentally swallowed seek medical advice immediately.

Capacity: 10ml per Pen

Contains: **Water 89.7% / Edetic acid 5.1% / Alcohols, C9-11, Ethoxylated 3.9% Potassium citrate monohydrate 1.2%, Essence 0.1%**



Product Code: P222351

Made in China for S&S Enterprises Ltd. 26 Perivale Park Middlesex UB6 7RL