

LED Angel with Trumpet

K906 v001: 23/05/22

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife



Dimensions

(H) 40 x (W) 34 x (D) 1cm

Length of lead to battery box: 50cm

Material: Iron

- IP44 RATED AND WATERPROOF BATTERY BOX
- 80 WHITE LEDS (not replaceable)
- TIMER FUNCTION – 6 HOURS ON 18 HOURS OFF.
- MAKES A GREAT CENTRE PIECE FOR YOUR GARDEN THIS CHRISTMAS.
- THE 80 LEDS SCATTERED AROUND THE ANGEL CREATES A WONDERFUL SILHOUETTE
- WITH THE 2 LONG GROUND STAKES YOU CAN SECURE FAR INTO THE GROUND SO IT IS FIRMLY IN PLACE

Required: 3xAA 1.5V batteries (not included)

**ALWAYS USE ALKALINE BATTERIES.
DO NOT USE LITHIUM BATTERIES.**

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the ornament.

TIMER/ ON/OFF

IMPORTANT:

1. LED fairy lights with 3xAA batteries (batteries not included) and operated without mains plug. The lights are designed for indoor and outdoor use. The battery box is waterproof.
2. Timer function: Copper wire lights have manual timing function. When you press the timer to select, the light chain turns on automatically for 6 hours and turns off every day for 18 hours. Timer function will be cancelled when changing the setting to OFF.



MAINTENANCE AND TROUBLESHOOTING:

1. Make sure the BUTTON is set to "OFF" position when not in use.
2. Battery operated LED lights are made of only the highest quality LED light diodes and silver-plated copper wire, low consumption and high efficiency. The LED light chain will not overheat after many hours of use. Stays cool all night and completely safe for your children and pets.
3. If product does not light up, replace the batteries as they may be weak or worn out. (Battery 3x AA 1.5v – Same equivalent type as recommended must be used.

**The Enterprise
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.
Please check with your telephone supplier.

BATTERY REPLACEMENT:

- Step1: Remove battery compartment cover.
- Step2: Remove the exhausted battery and install 3x new AA battery according to the polarity symbol indicated on the battery compartment. Open the compartment carefully and ensure that welding wires inside the battery terminals are not damaged.
- Step3: Replace battery compartment cover, set it back into position and make sure it is properly sealed.




BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer’s safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product’s lifespan please check with your local council authorised household waste recycling centre for disposal.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	ABS
Commonly used for	CD’s, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

