20 LED Wooden Tree K971

Instructions for Use

Please read and retain these instructions for future reference

v001: 20/06/22



Dimensions

(H) 40 x (W) 27 x (D) 6cm Material: Plywood

- FESTIVE WINTER NIGHT SCENE WITH REINDEER NEXT TO CHRISTMAS TREES
- BACK LIT WITH LEDS FOR A GENTLE WARM WHITE GLOW
- PERFECT FOR A TRADITIONAL OR MODERN FESTIVE DISPLAY
- STARS ECHO THE TRADITIONAL CHRISTMAS STORY
- ELEGANT ORNAMENT
- IDEAL TO DISPLAY ON TABLE TOP, MANTELPIECE, SIDEBOARD OR WINDOW SILL
- FULLY ASSEMBLED
- 20 LEDs (not replaceable)

Requires 2x AAA batteries (not included) Indoor use only.

This is not a toy. Keep away from children.

INSTRUCTIONS FOR USE:


Unpack all components carefully. Please check all parts have been removed from the packaging.

Installing the batteries

- Pull the plastic separator towards the outer left, then open the lid.
- Install 2x AAA batteries.
- Turn the switch to the "ON" position.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.



20 LED Wooden Tree к971

Instructions for Use

Please read and retain these instructions for future reference

v001: 20/06/22

Care and Maintenance

- Handle with care.
- Always switch off and remove batteries when not in use.
- Do NOT immerse in water.
- Store the item in a cool, dry place and away from children.
- Wipe with a clean dry cloth.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	LDPE
Type of Plastic	Low Density Polyethylene
Commonly used for	Shopping bags, bread bags, squeezy bottles, stretch/pallet wrap, bubble wrap, multi-pack can holders
Notes	Usually recyclable supermarket deposit points. Check other plastic films as any non-polythene film e.g. cling film, crisp packets film lids

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



Please check with your telephone supplier.