

# 60cm Light Up Tree Stake

**L011** v001: 25/05/22

Please read and retain these instructions for future reference

**GAINSBOROUGH**  
Garden & Wildlife



## Dimensions

(H) 60cm

40CM WIDEST WIDTH AND 15CM NARROWEST WIDTH

- 50 WARM WHITE LEDS
- IP44 RATED BATTERY CASE
- 6HOUR TIMER – 6 HOURS ON 18 HOURS OFF.
- USE TO LINE PATHS, FLOWER BEDS ETC.
- STAKE IS 16CM
- ADJUSTABLE BRANCHES ALLOW YOU TO FLEX AND POSITION WHERE DESIRED.

Required: 3x AA batteries (not included)

Power: 4.5V DC, 1W

**ALWAYS USE ALKALINE BATTERIES.**

**DO NOT USE LITHIUM BATTERIES.**


## ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base.

### Before use:

Remove the battery compartment cover. Insert 3x AA batteries (not included), observing correct polarity as indicated in the battery compartment. Replace the battery compartment cover.



**The Enterprise  
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
Please check with your telephone supplier.

- Press button once for timer function 6 HOURS ON 18 HOURS OFF
- Press button again for ON continuously
- Press button again to switch off


**BATTERIES**

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

**DISPOSAL**

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.
- Plastics, polybags – Contains the following recyclable plastic



Code & Symbol	 OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

