


Solar Light Up Reindeer Stake

L014 v001: 25/05/22

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

Always position in direct sunlight.



Dimensions

(H) 79.5 x (W) 26.5 x (D) 5cm

- SOLAR POWERED
- REINDEER SHAPED LIGHTS LOOK AS THOUGH THEY ARE FLYING THROUGH THE AIR
- 22 WARM WHITE LEDS.
- AUTOMATICALLY ILLUMINATE AT DUSK.
- IP44 RATED

Required: 1x Ni-MH AAA 300mAh 1.2V (included)

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Connect the stake with the ornament by twisting them together. To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.



CHARGING AND OPERATION:

1. Set button which is located underneath the solar panel to "ON" position for charging and charge by placing it under direct sunlight for at least 8 hours.
2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to verify that the button is correctly in the "ON" position, cover the solar panel with your hand and light should turn "ON" automatically.



**The Enterprise
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.

Please check with your telephone supplier.

IMPORTANT:

1. Place the item in an area where it can get direct sunlight.
2. Leave the button to "ON" position.
3. Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.
4. Duration of light depends on solar product's level of sunshine exposure, geographical locations, weather conditions and the hours of daylight.

MAINTENANCE AND TROUBLESHOOTING:

1. Make sure the switch is set to "ON" position.
2. Keep the solar panel clean.
3. Battery 1x AAA " 1.2v 300Mah, Ni-MH, Rechargeable, Non-replaceable).


BATTERIES

- Keep batteries away from children and pets.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	Please Specify (includes ABS, Nylon)
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

