## Stretch Watch & Tennis Bracelet L975 Instructions for Use

Please read and retain these instructions for future reference

v001: 02/08/23



#### **Dimensions**

WRIST SIZE (WATCH) 14.5 - 27.5 CM (BRACELET) 18 - 24.5 CM WATCH FACE SIZE 3.2X3.7 CM

Battery: LR626 BUTTON CELL

Voltage details: 1.5V

Included

### **Composition:**

70% STAINLESS STEEL, 30% ZINC ALLOY

- INCLUDED WITH PACK OF 2:
- STRETCH AND TENNIS BRACELETS.
- USING RHINESTONES
- 28 PCS CRYSTALS ON WATCH
- 42PCS CRYSTALS ON BRACELET
- THE WATCH IS A QUARTZ WATCH
- NOT FOR USE IN WATER.

Please read this instruction manual thoroughly before starting and ensure you are familiar with the operation of your new Stretch Watch and Tennis Bracelet.

This watch comes with an expansion band that should not need to be adjusted. To replace, carefully remove pins from the lug from the rear of the bezel. It is recommended that you take your watch to a professional jeweller or watch repairer for assistance.

#### TIME SETTING:

 To set the time, pull up on the crown and rotate clockwise or counterclockwise to the correct time. Depress the crown until you hear a click – your watch is now set.

#### **BATTERY REPLACEMENT:**

- This watch uses a 377 / AG4 button cell battery.
- It is recommended that you take your watch to a professional jeweller or watch repairer for assistance in replacing the battery to ensure the water-resistant seal is not damaged.



### Stretch Watch & Tennis Bracelet L975 Instructions for Use

Please read and retain these instructions for future reference

v001: 02/08/23

#### **WARNINGS AND SAFETY INSTRUCTIONS:**

WHEN USING ANY APPLIANCE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED:

- READ ALL INSTRUCTIONS BEFORE USE.
- BEFORE USE, CHECK THOROUGHLY FOR ANY DEFECTS AND DO NOT USE IF DEFECTS ARE FOUND. TAKE CARE NOT TO DROP THE WATCH AS HEAVY IMPACTS MAY CAUSE INTERNAL DAMAGE.

#### **BATTERIES:**





#### **CONTAINS BUTTON CELLS**



immediately.



#### **BATTERY SAFETY:**

- BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN. IF SWALLOWED OR PLACED INSIDE ANY PART OF THE BODY SEEK IMMEDIATE MEDICAL ATTENTION.
- INSTALL BATTERIES IN ACCORDANCE WITH ITS POLARITY SYMBOLS. DO NOT FIT BUTTON CELLS IN REVERSE.
- DO NOT SHORT CIRCUIT THE BATTERY TERMINALS.
- DO NOT MIX USED AND NEW BUTTON CELLS
- KEEP BUTTON CELL BATTERIES AWAY FROM CHILDREN AND PETS.
- NEVER DISPOSE OF BUTTON CELLS OR BATTERIES IN A FIRE.

#### CARE AND CLEANING INSTRUCTIONS

- SPENT BATTERIES TO BE REPLACED BY A JEWELLER TO WATCH REPAIRER.
- DO NOT USE OR IMMERSE IN WATER.
- DO NOT USE ABRASIVE CLEANERS.
- WIPE SURFACES WITH A SOFT DRY CLOTH.




# Stretch Watch & Tennis Bracelet L975 Instructions for Use

Please read and retain these instructions for future reference

v001: 02/08/23

#### **DISPOSAL:**

- SPENT OR EXPIRED BUTTON CELLS MUST BE DISPOSED SAFELY AWAY FROM CHILDREN AND RECYCLED IN COMPLIANCE WITH YOUR LOCAL AUTHORITY REGULATIONS.
- FOLLOW THE BATTERY MANUFACTURER'S SAFETY, USAGE, AND DISPOSAL INSTRUCTIONS.
- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons in accordance with your local authority recycling regulations.





#### **CUSTOMER SERVICES:**

Customers in GB (England, Scotland and Wales), please contact our customer services

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU, Tel: 0330 331 0300

Customers in Northern Ireland and Europe, please contact our customer services - D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France, Tel: (+44) 1279 701269



