

42L WHEELED RECYCLING KITCHEN BIN

Item codes: M125



Instructions for Use

v001: 13/10/23

Please read and retain these instructions for future reference



KEY:



INSTRUCTIONS FOR USE

1. Fasten the bin container (2) with lid (1).
2. Put (A) in the middle of (2) and fasten both sides.
3. Place (B) on the left side of the top of the bucket and (C) on the right side of the top of the bucket.
4. Clip the bottom of (2) into the top of (3) making sure the bin container and drawer are in same direction)
5. Put (4) into (3).
6. Put (D) in the middle of (5), Place E on the left side of the top of (5) and Put F on the right side of top of (5).
7. G - Two wheels with brakes mounted on the front of the bin, Two without brakes in the back. (Drawer box faces the front)
8. Clip bottom of (3) into the top of (5)

CARE AND CLEANING INSTRUCTIONS:

- Do NOT use abrasive cleaners or sharp utensils to clean this product.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons in accordance with your local authority recycling regulations.
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



CUSTOMER SERVICES:

Distributed by / Verteilt durch / Distribué par.

UK: The Enterprise Department Ltd.
11 Bridge Street, Bishops Stortford, Herts, UK, CM23 2JU
Tel: 0330 331 0300

NI/EU:
D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France
Tel: (+44) 1279 701269