

Atomic Radio Controlled Digital Alarm Clock

Item codes:M262

Instructions for Use

v002: 14/12/23

Please read and retain these instructions for future reference

BERGSTRÖM

Dimensions

H14.6 xW9.7 xD5.7cm

Composition

50% ABS, 30%LCD, 20%PCB

FEATURE

Alarm and snooze Never be late again!
Displaying time, date, day and temperature in large,
Easy-to-read numbers, this cordless digital clock is
Not only unbelievably accurate, it also displays
Fahrenheit (°F) and Celsius (°C).
Background illuminates at night for easy reading.
2x AAA batteries required.



INSTRUCTIONS FOR USE:

START-UP (Radio controlled clock)

1. Open the battery compartment and put the batteries in it.
2. When inserting the batteries, the clock will scan the MSF frequency signal (⚡ flashes on the LCD if the signal is OK).
3. The clock automatically scans the time at 1:00 a.m. every day to maintain accurate timing. For failed reception in 5 minutes, scanning stops and repeats again at 2:00 a.m. and 3:00 a.m.
4. The clock manually scans the time signal by holding "WAVE" for 2 seconds. For failed reception in 5 minutes, scanning stops.
5. ⚡ turns on the indicate signal received successfully.
6. After 10 minutes, if the clock has not received the MSF signal and signal strength icon will disappear from the LCD display.

Manual Time Setting

1. When the LCD displays the TIME, hold the "MODE" button for 2 seconds to enter Clock/Calendar setting.
2. The setting sequence is shown as follow: 12/24H display, Hour, Minute, Year, Month, Date
3. Press "UP" or "DOWN" buttons to adjust the setting.

Adjust The Daily Alarm

1. Hold the "ALARM" button for 2 seconds to enter ALARM time setting. Press "UP" or "DOWN" button to adjust the ALARM time.
2. Press the "ALARM" button to switch ALARM on or off.

Other usage

1. Press "DOWN" button to select temperature in Celsius mode or Fahrenheit mode.
2. Buttons except "WAVE" will have no function while scanning for MSF signal.
3. All setting Mode will automatically exit in 30 seconds without any adjustment.

Button Function:

MODE ALARM UP DOWN WAVE

WARNINGS AND SAFETY INSTRUCTIONS:

WHEN USING ANY APPLIANCE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED:

- READ ALL INSTRUCTIONS BEFORE USE.
- FOR DOMESTIC INDOOR USE.
- NOT FOR COMMERCIAL USE.
- BEFORE USE, CHECK THOROUGHLY FOR ANY DEFECTS AND DO NOT USE IF DEFECTS ARE FOUND. TAKE CARE NOT TO DROP THE APPLIANCE AS HEAVY IMPACTS MAY CAUSE INTERNAL DAMAGE.
- THE USE OF ANY ACCESSORY OR ATTACHMENTS NOT RECOMMENDED BY COOPERS OF STORTFORD MAY CAUSE INJURIES AND INVALIDATE ANY WARRANTY YOU MAY HAVE.

- DO NOT PLACE ON OR NEAR HEAT SOURCES.
- DO NOT COVER THE ITEM IN ANY WAY WHEN IN USE AS THIS MAY CAUSE OVERHEATING.
- DO NOT USE THIS APPLIANCE FOR ANY OTHER USE THAN THE INTENDED USE IT IS DESIGNED FOR.
- DO NOT LEAVE SWITCHED ON OR UNATTENDED.

BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN. IF SWALLOWED OR PLACED INSIDE ANY PART OF THE BODY SEEK IMMEDIATE MEDICAL ATTENTION.

- INSTALL BATTERIES IN ACCORDANCE WITH ITS POLARITY SYMBOLS. DO NOT FIT BATTERIES IN REVERSE.
- DO NOT SHORT CIRCUIT THE BATTERY TERMINALS.
- REMOVE THE BATTERIES IF LEFT FOR LONG PERIODS.
- **KEEP BATTERIES AWAY FROM CHILDREN AND PETS.**
- DO NOT MIX USED AND NEW BATTERIES.
- **NEVER DISPOSE OF BATTERIES IN A FIRE.**
- BATTERY DISPOSAL, SPENT OR EXPIRED BATTERIES MUST BE DISPOSED OF AND RECYCLED IN COMPLIANCE WITH YOUR LOCAL AUTHORITY REGULATIONS.
- FOLLOW THE BATTERY MANUFACTURER'S SAFETY, USAGE, AND DISPOSAL INSTRUCTIONS

CARE AND CLEANING INSTRUCTIONS

- ALWAYS SWITCH OFF AND REMOVE BATTERIES BEFORE CLEANING.
- DO NOT IMMERSE IN WATER.
- DO NOT USE ABRASIVE CLEANERS OR SHARP UTENSILS TO CLEAN THIS APPLIANCE.
- WIPE SURFACES WITH A SOFT DRY CLOTH. DRY THOROUGHLY BEFORE FURTHER USE.
- STORE THE APPLIANCE IN A COOL, DRY PLACE.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packing, paper, cartons, packaging in accordance with your local recycling regulations.



CUSTOMER SERVICES:

Distributed by / Verteilt durch / Distribué par.

UK: The Enterprise Department Ltd.
11 Bridge Street, Bishops Stortford, Herts, UK, CM23 2JU
Tel: 0330 331 0300

NI/EU:
D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France
Tel: (+44) 1279 701269

UK
CA

