


# Saw Horse<sup>5924</sup>

Please refer to diagrams when assembling the Saw Horse

1. Attach lower horizontal bar (B) to end vertical bar (A) using long bolt (1) and nut (3) ensuring the screw holes on the side of the end vertical bar are above the lower horizontal bar.
2. Attach upper horizontal bar (D) to vertical bar (A) using long bolt (1) and nut (3). Attach the second end vertical bar (A) to both end horizontal bars using 2x long bolt (1) and 2x nut (3).
3. Attach diagonal bar (C) to the assembled section using 2x long bolt (1) and 2x nut (3).
4. Attach the middle vertical bar (E) to the horizontal bars (B+D) using using 2x long bolt (1) and 2x nut (3). This bar does not fix onto the diagonal bar (C).
5. Attach "J" hook (9) to the middle vertical bar (E) using nut (10), 2x washer (12) and locking nut (11). Repeat process for other middle vertical bar (E).
6. Repeat steps 1-5 to assemble the other side of the Saw Horse. **Note only one side has an upper horizontal bar.**
7. Join the vertical bars (A+E) of both assembled sections and fix using 3x long bolt (1) and 3x locking nut (2).
8. Fit both long chains (6) as shown in the diagram to prevent the Saw Horse from opening too far.
9. Attach the short chain (8) to one of the "J" hooks (9) and the spring hook (7) to the other "J" hook (9) to hold log firmly in place.
10. Tighten all nuts and bolts fully before use.



No.	Part	Specification	Qty
(1)	Long bolt	M8 x60	16
(2)	Locking nut	M8	3
(3)	Nut	M8	13
(4)	Bolt	M6 x35	4
(5)	Locking nut	M6	4
(6)	Long chain	400mm	2
(7)	Spring hook		1
(8)	Short chain	300mm	1
(9)	J hook		2
(10)	Nut	M5	2
(11)	Locking nut	M5	2
(12)	Washer	M5 x16 x1.2	4

## WARNING

- Do **NOT** use the Saw Horse without both chains (6) in position.
- Periodically check all nuts and bolts are secure.
- Do **NOT** use if any nuts and bolts are not fully secure
- Do **NOT** use on uneven or sloping surfaces.
- Wear appropriate protective footwear, gloves, dust mask and eye protection at all times when sawing.
- Keep children and pets well away from the area during use.
- Use in well ventilated area.
- Take care when fixing and unfixing the spring hook (7) to hold logs in place.

## DISPOSING OF PACKAGING

- Dispose of the packaging at your local recycling centre.
- Dispose of paper and carton separately from plastic bags at your recycling centre.
- Dispose of the item at the end of its usefulness at your local authorised household waste cycling centre.

Head Office: 11 Bridge Street,  
Bishop's Stortford CM23 2JU  
Tel: 0844 482 4400 Fax: 01279 756595

**Coopers**  
OF STORTFORD