



Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400 Fax: 01279 756595

Drain **Magic** Instructions







Drain Magic Instruction Manual

Thank you for purchasing this product. This instruction manual explains the basic operation and safety aspects of this product.

General Safety

For safety reasons, read these instructions carefully before operating Drain Magic. Anyone who is not familiar with this manual must not use this product. We strongly recommend that you keep this manual in a safe place for future reference.



Do not use this device if the nozzle or adapters are blocked. It must not be used for any other purpose than that intended as damage may occur which will invalidate your warranty. Do not open the Drain Magic!

Maintenance

Clean Drain Magic with a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent, such as alcohol or benzene. When stored away, do not expose Drain Magic to excessive sun light or humidity. Lubricate the air pump shaft from time to time when needed using silicon-oil only!



Instructions

 When clearing a toilet u-bend, select the correct diameter adapter, pump the device a maximum of 40 times.



 When clearing a sink, please ensure the overflow is covered A and the U bend is supported B it is recommended that there is at least 7cm of water in the sink C.



