

Product features

- 10x 3x magnifiers.
- UV light to assist in detecting counterfeit bank notes.
- LED reading light & torch.
- Pull out pen.
- Protective sleeve.

Product requires 3x LR927 batteries (included). Pull out insulating strip before first use. To replace batteries, remove back and replace with 3x LR927 batteries only. Observe (+ & -) polarity when changing batteries.

WARNING!

DO NOT LOOK DIRECTLY AT THE SUN THROUGH THE LENS. DO NOT LOOK DIRECTLY AT THE LED AND UV LIGHTS.

INSTRUCTIONS FOR USE:

- Press button once for LED torch light.
- Press second time for UV light.
- Press a third time for LED reading light.
- Press again to turn off.

CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do not shine light directly towards eyes.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.



- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.

