

Read all instructions carefully before use and retain for future reference.


- Only use the epilator as described in these instructions.
- Keep out of reach of children.
- This item must not get wet. Do not use in a bath or shower. This item is not waterproof.
- Only for use on clean dry skin. Do not use with lotions.
- Do not use on any skin with abrasions, spots, moles, wounds, acne, eczema, sunburn, rosacea, varicose veins etc. (this list is not exhaustive). If you have any kind of skin condition or medical condition, or a pacemaker, always check with your doctor or medical practitioner before use.
- Always test a small patch of skin and wait 24 – 48 hours to ensure there are no adverse reactions.
- Removing hair from the root may cause ingrown hair and skin irritation. If you are prone to ingrown hair this unit may not be best for you.
- It is not advisable to share the epilator due to hygiene and health reasons.
- Keep away from hair on your scalp, eyebrows and eyelashes, loose clothes etc.
- Never use if the unit has been damaged.
- Do not use where aerosol products are being used.
- Always keep the epilator clean to minimise the risk of infection.
- Not intended for use on the whole face like an electric shaver.
- Not intended to remove men's facial hair.
- Not for commercial use.

Batteries

- The unit requires 2x AAA batteries not supplied. Slide open the ribbed panel and insert batteries observing the correct polarity.

Using the Epilator

- Using an epilator may cause redness or irritation of the skin. This is a normal reaction that will disappear quickly. However, those with sensitive skin may find this takes longer. Try using the epilator on the back of your hand to see how this will feel. Try using the epilator in the evening so that any redness will reduce by morning.
- Always test a small area first and leave 24 – 48 hours to ensure there are no adverse reactions.
- The discs may have factory residue or grease. Clean using a cotton bud and rubbing alcohol.
- For best results, have a warm bath or shower to open your pores and use a loofah sponge or similar to exfoliate skin (not supplied).
- Trim any hair longer than 5mm.
- Ensure skin is dry, clean and free from creams or oil.
- Pull skin very taut to avoid pinching and help minimise discomfort.
- Slide the on button upwards to start the unit.



- Hold the epilator at a 90° angle to the area you are removing hair from.
- There is no need to apply pressure.
- Move the epilator in rapid circles, lightly gliding over the skin.
- The epilator may be used to remove individual face hairs on the upper lip, chin and cheek area. It is not for use on eyebrows. Take extra care near your lips holding the skin as taut as possible. Do not use the epilator like a man's shaver on your whole facial area.
- The unit can also be used on arms, legs, bikini and other body areas.
- Use a cool, damp cloth or lotion to calm the skin after using the unit.

Cleaning

- Clean after each use.
- Use the small brush included to brush hairs away.
- The discs may be cleaned using a cotton bud and rubbing alcohol. Make sure it is not soaked with liquid as this will damage the unit.

Packaging

- Dispose of the packaging at your local recycling centre.
- Dispose of paper and carton separately from plastic bags at your local recycling centre.
- Dispose of the item at the end of its lifespan at your local authorised household waste recycling centre.