

20 LED Reading Light 8831

Safety instructions

1. Remove the base cover and insert 3 x D batteries (alkaline batteries are recommended), ensuring that the plus (+) and minus (-) poles are correctly observed. Failure to properly align the battery polarity can cause personal injury and/or damage to the lantern.
2. Press the switch once for 10 LEDs and again to turn off. Press a third time for 20 LEDs and again to turn off.

WARNING



Do not stare into the beam; this is a class 2 LED product, damage to your eyes may occur.



Storage

Remove the batteries if left for long periods. Store the unit in a cool, dry place.

Cleaning

Use a damp cloth to clean the lantern, dry with a soft cloth.

Do not use water or other liquids or solvents to clean the lantern.

Do not immerse in water.

Packaging

Dispose of the packaging at your local recycling centre. Dispose of paper and carton separately from plastic bags.

Dispose of the appliance at the end of its lifespan at your local authorised household waste recycling centre.

Batteries

Keep batteries away from children and pets.

Do not mix used and a new battery, or mix different battery types.

Remove spent or expired batteries from the lantern. Remove the batteries when the lantern will not be used for extended periods of time.

Never dispose of batteries in a fire.

Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.

Follow the battery manufacturer's safety, usage, and disposal instructions.

Caution

This is not a toy; keep out of the reach of children.

The LED bulbs are not replaceable; do not attempt to open the lantern housing.

Do not leave the lantern exposed to bad weather conditions or out doors for prolonged periods.

The lantern does have an optional DC input; we do not support this feature, or supply an adapter.

