

PARTS

1. Mode selection button
2. LED indicators
3. DC power supply socket
4. Battery cover
5. Adjustable clip
6. Ground stake upper section
7. Ground stake lower section

ASSEMBLY

Before use:

- Unscrew and remove battery cover.
- Fit 2x 9V batteries.
- Replace the battery cover and tighten the screws.
- Alternatively, remove cover from 9V optional DC Adaptor outlet, fit the 9V DC adaptor and plug into the mains.
- The LED lights on the front will flash once the repeller is powered.

For outdoor use:

- Attach the lower section of the ground stake (7) to the upper section of the ground stake (6).
- Attach the clip (5) into the top of the upper section (6) of the ground stake.
- Attach the clip to the repeller head and set to the lower position.
- Place ground stake into the ground in the desired location.

For indoor use:

- Attach the clip to the repeller head and set to the higher position.
- Place the repeller head in the desired location.

OPERATION

The Ultrasonic PIR Clear Deluxe has 5 working modes:

Indicator	Mode
Yellow	Ultrasound, alarm and flashing LEDs
Green	Flashing LEDs
Red	Ultrasound and alarm.
Red flashing	Illuminated LEDs (30 seconds)
Green flashing	Ultrasound (intermittent pulses for 40 seconds)

- Select the desired mode using the mode selection button.
- The repeller will take a short period (approx. 30 seconds) to set itself to each mode. After this period, the repeller will be triggered when activated.
- Once the repeller has set itself to the desired mode, the LED indicator on the side will no longer be illuminated.
- To turn off the repeller, press and hold the mode selection button. The LED lights on the front will again flash once as the repeller is turned off.
- Ultrasonic PIR Clear Deluxe repels cats, dogs, birds, foxes, squirrels, rabbits, mice, etc. from the home, garden, flower beds, garages, outbuildings, etc...



Sold Separately

WARNING

- Always ensure you observe the correct polarity when inserting batteries.
- If performance becomes reduced, the batteries may need to be replaced/recharged.
- Always turn off before replacing batteries.
- Dispose of batteries in accordance with local authority guidelines.
- Please note that if using rechargeable batteries, the period of time that the battery will hold charge will decrease during the life of the battery. All rechargeable batteries have a finite number of charge cycles.
- Do NOT look directly into the LED lights on the front for extended periods.
- Whilst the repeller is water resistant, do NOT submerge in water.
- Do NOT hold directly to the ear.
- For domestic use only.

CLEANING & STORAGE

- If the item is not to be used for an extended period, it is recommended that the unit is switched off to preserve the batteries. Remove the batteries and store separately.
- Before storage, wipe clean with a soft damp cloth, allow to dry fully and store indoors.
- Do NOT use solvents or abrasives.
- Clean regularly as a build-up of dirt over the PIR sensor will reduce performance.

TECHNICAL INFORMATION

Power supply:	2x 9V battery or mains powered 9V adaptor
Passive Infrared area:	70m ²
Passive Infrared angle:	110°
Frequency:	15-26kHz
Audio Frequency:	approx. 7kHz
Output sound pressure:	110dB
IP level:	IP44

DISPOSAL:

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local battery waste regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.



PestReach
There's nowhere to hide!

Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

Coopers
OF STORTFORD

*Calls cost 7 pence per minute plus your telephone company's network access charge