

Spare Bowl for Home-made Ice Cream Machine 9531

Instructions

BEFORE USE

- Clean before first use and dry thoroughly.
- Place the freezer bowl in the upright position into a freezer at least 8 hours before making the ice cream. Place freezer bowl in a plastic bag before freezing.

OPERATION

1. Remove the freezer bowl from the freezer and attach the assembled lid/power unit/paddle and turn anti-clockwise to lock into position. Note: Do not remove the freezer bowl from the freezer until ready to make ice cream. Take care when handling the frozen bowl, do not touch any of the metal parts with bare fingers.
2. Follow Ice Cream Machine instructions to make ice cream.

Important

- Do not use metal utensils to remove the mix from the bowl.
- Do not use sharp objects or utensils inside the bowl as they may scratch or damage the interior surfaces.
- The freezer bowl can be kept in the freezer so that it is ready for use.
- Always make sure the freezer bowl is thoroughly dry before placing in the freezer.
- Do not puncture or heat the freezer bowl to defrost.
- The freezer bowl should be placed in a freezer with an operating temperature at -18°C (-0.40°F) or below.
- The addition of alcohol to recipes inhibits the freezing process. Place ice cream or sorbets made using alcoholic ingredients into the freezer to harden fully before consumption.

WARNING

- Check for damage before use. Do not use if any part is damaged including the plug or power cord.
- Never use an unauthorised attachment.
- For indoor, domestic use only.
- Ensure that all parts are thoroughly clean before use to prepare food.
- Never re-freeze ice cream that has been fully or partially defrosted.
- Any ice cream or sorbet containing raw ingredients should be consumed within one week from the date it was made. Ice cream tastes best when fresh.
- Ice cream or sorbet that contains raw or partially cooked eggs should not be given to young children, pregnant women, the elderly or people who are generally unwell.
- It is strongly recommended to wear gloves when handling the frozen freezer bowl. Do not touch any of the metal parts of the freezer bowl with bare hands when it is frozen.
- If the freezing solution appears to be leaking from the bowl, discontinue use immediately. The freezing solution is non-toxic.



CLEANING

- Allow the freezer bowl to reach room temperature before attempting to clean. Wash the inside of the bowl using warm, soapy water then dry thoroughly. Do not immerse in water.
- Not dishwasher safe.
- Do not clean with scouring powders, steel wool pads, or other abrasive materials.

DISPOSAL

Dispose of all paper, cartons and plastic in accordance with your local recycling regulations. At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.

Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU
Tel. 0844 482 4400
Fax. 01279 756595
www.coopersofstortford.co.uk


Mrs Cooper's
Home-made
Ice Cream Machine