

3W CREE Rechargeable Torch 10690 Instructions for Use

Please read and retain these instructions for future reference

v004: 22/07/20



TECHNICAL DETAILS:

TRANSFORMER MODEL:	IPX3
INPUT VOLTAGE:	100-240V a.c.
OUTPUT VOLTAGE:	4.5V d.c. 500ma.
POWER FREQUENCY:	50-60 Hz
WATTAGE:	3W
BATTERY DETAILS:	Lithium-Ion 2200mAh (included)

BATTERY INSTALLATION:

- **BEFORE FIRST USE:**
There is a small plastic insulating disc in the battery compartment to protect the battery in transit. This must be removed before use. Unscrew the cover and remove the disc.
- Install the battery with the positive end (with groove) towards the torch head, then replace the cover.
- The battery is pre-charged. **Do not charge before first use.**
- When light from the torch becomes dull, it is time to recharge the battery

RE-CHARGING:

- Remove the cover from charger socket and plug the charger into the torch.
- When the charger is plugged into the mains socket, the charger LED will be green.
Plug the charger into the socket on the torch.
- When charging, the charger LED will be red.
- Once the torch is fully charged, the LED will turn green.
- Always discharge the torch fully before recharging.
- Once fully discharged the battery will take up to 7 hours to re-charge.



3W CREE Rechargeable Torch 10690 Instructions for Use

Please read and retain these instructions for future reference

v004: 22/07/20

OPERATION:

- To turn the torch on, press the black button on the shaft of the torch until it clicks.
- The torch has 3 different functions: High beam, normal and flashing. To switch between the functions, gently press down the black button.
- To turn off, press the black button in until it clicks again.
- Once performance reduces, the torch will need to be recharged.

CLEANING:

- Wipe clean with a soft cloth.
- **Do NOT** use abrasives.

WARNING:

- NEVER POINT THE TORCH DIRECTLY TOWARDS YOUR EYES OR THE EYES OF OTHERS.
- DO NOT OVER CHARGE OR CHARGE FOR LONGER THAN 7 HOURS.
- ONLY USE WITH THE TRANSFORMER PROVIDED.
- OR USE WITH SIMILAR RECHARGEABLE BATTERY PROVIDED.


BATTERIES:

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	Please Specify (includes ABS, Nylon)
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.