




PARTS




Part	Description	Qty
A	Top panel	1
B	Side panels	2
C	Tray bases	2
D	Base section	1
E	Tray side panels	6
F	Wheels	4
G	Cam locks	28
H	Screws	16

TOOLS

Cross-head screwdriver
(not supplied)



1. Attach the tray side panels (E) to the tray bases (C) and base section (D) using 4x cam locks (G) per tray.



2. Attach the assembled trays to one of the side panels (B) using 2x cam locks (G) for each tray.



3. Attach the second side panel (B) using 2x cam locks (G) for each tray.



4. Attach top panel (A) using 4x cam locks (G).



5. Upright the assembled Lounge Trolley and attach 4x wheels using screws (H).



6. Upright the unit again.

WARNING

- Take care when manoeuvring the trolley if it has hot liquids on.
- Check to ensure all fixings are securely tightened before use.

CLEANING

- Wipe clean with a soft, damp cloth.
- Periodically check that all fixings are secure and tighten if necessary.

DISPOSAL

- Dispose of all paper, cartons and plastic in accordance with your local recycling regulations. At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.