

Memory Foam Neck Massager Instruction Sheet

Product Code: G100079



Thank you for purchasing our Neck Massager. This product will relax tense neck and shoulder muscles and may help relieve tension and stress headaches.

INSTRUCTION FOR USE:

1. Remove the Neck Massager from its carrying bag
2. Unzip the product to reveal battery compartment
3. Insert 2 x AA batteries (not included)
4. Zip the product up to hide battery compartment
5. Place the unit around your neck or shoulder
6. Choose HIGH or LOW intensity setting
7. The product is ready to use

I: LOW SETTING

O: PRE-SET

II: HIGH SETTING

Not suitable for use pacemaker users



Made in China

Imported by: S&S Enterprises Ltd, 27 Perivale Park, Perivale, Middlesex, UB6 7RL