










Parts:




- A  3.5x30MM 12PCS
- B  3.5x35MM 8 PCS
- C  M6x 50MM 9PCS
- D  30x16 MM 13 PCS
- E  35x16MM 4 PCS




Assembly instructions

Step 1: Attach the Door Part 1A to the Door Frame Part 1 by using 4x Part E


Step 2: Attach the Side Panels Parts 3A & 3B to the Door Frame Part 1 and the Back Panel Part 2 with 12x Screws Part A










**Step 3: Place the Top Shelf pieces
Part 8 in place in the top of the
frame.**

**Step 4: Insert the Base Panel Part 5
into the bottom of the frame. Next
insert and attach the Shelves Part 6
by using 6x Part C Nuts and Bolts**




Step 5: Attach the Shelves to the Back Panel Part 2 by using 3x Part C Nuts and Bolts.



Step 6: Attach the Roof Part 4 to the main frame by using Part B Screws.

Then fix the Catch Part 4 and Lock Part 3 onto the Shed.



Step 7: Attach the Wooden Middle Bar Part 7 across the middle of the roof with 4x Part 7 Screws.

WARNINGS / CAUTIONS:

- Place on a level surface

CLEANING INSTRUCTIONS: Use a soft brush or cloth.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.