Please read and retain these instructions for future reference

v001: 05/11/18




INSTRUCTIONS FOR USE:


Item ships in the OFF position. To turn ON, rotate solar panel component (A) several inches in any direction until the ON/Off button (C) is pressed against the vase rim and the UV light is turned ON. Place bug killer away from light. Note: bug killer only works in the dark.

Optional: Install the handle (G) inside small holes on the sides of the vase to hang the bug killer from a desired location.

Maintenance

Rotate the solar panel component (A) until the UV light OFF/ON button (C) is in the small gap inside the vase rim and UV light is turned off (D). Pull the solar panel component (A) out from the vase (B). Rotate screen (F) counter-clockwise to remove. Use a cleaning brush to dust and remove dead insects from the wiring (E). Replace screen (F) and solar component (A).





Caution Potential Shock Hazard

Do not touch UV light wiring (E) when UV light is turned on (D).

Head Office, 11 Bridge Street, Bishop's Stortford CM23 2JU Tel: 0844 482 4400* Fax: 01279 756 595 www.coopersofstortford.co.uk



Please read and retain these instructions for future reference

v001: 05/11/18

Siting your bug zapper:

Place away from other sources of light, i.e. street lights, as this light may prevent the sensor to operate correctly.

- Ensure that the item is not placed in a shady position as this will prevent the batteries from charging correctly.
- Weather conditions and season will affect how much the battery is able to charge during the day.

CARE AND CLEANING INSTRUCTIONS:

- Ensure that the solar panel is always clean in order to obtain the greatest possible collection of light. Occasionally clean with a damp cloth. Note: never use solvents or abrasive cleaning agents.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

BATTERIES:

- Charging Solar Rechargeable Battery
- Ni-Mh rechargeable battery included. Batteries are not replaceable.
- Never dispose of batteries in a fire.
- Keep batteries away from children and pets.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.



