

## Technical details:

Maximum load: 120kg

Dimensions: 193 x 63cm x 29cm

Sling material weatherproof PVC vinyl encapsulated polyester FR mesh material

Frame powder coated steel

## WARNINGS / CAUTIONS:


- Only one person should use and/or operate this sun lounger at any one time.
- This product has been designed for adult use.
- This product has been designed for light outdoor use only.
- Always open up the sun lounger and use on a level surface, never on a slope.
- All movements on this sun lounger should be slow and careful.
- Do not allow children to play on or around this sun lounger, particularly when it is in an open position.
- This sun lounger is designed to lie down on, not to sit on.
- When moving this sun lounger, please ensure it is in its securely folded closed position.
- When lying down on the sun lounger or when getting up from it the user's weight should be evenly distributed. See diagram below.




## How to unfold and fold:

CAUTION: Care should be taken at all times to keep your hands and fingers away from the mechanisms whilst folding and unfolding the lounger.

- Place the lounger on its side edge. Extend out the legs until you hear each one “click” into place as per the diagram below:



- Place the lounger onto its legs and use the tubes underneath the back to set the desired position angle.



- Reverse the steps above to fold the lounger after use.

## CLEANING INSTRUCTIONS:

- Wipe clean only.

## DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.