


### Garden Storage Box parts




### ASSEMBLY

1. Place the End without rollers (F) face down.
2. Slot in Front panel (A) and Back panel (B) into the End without rollers (F) ensuring the clips line up with the slots and clip into place.
3. Align the slots on Base (D) with the clips on the assembled section and clip into place, working from the ground upwards. Ensure all clips are securely fastened in position.

Note: The box should have the "grid" side facing downwards when complete.

4. Attach End with rollers (E) to the assembled section, making sure that the assembled section is correctly aligned with the grooves. Ensure clips are securely fastened in position.
5. Attach 2x Rollers (3) to the End with rollers (E) ensuring they clip into position correctly.
6. Attach Cover (C) to assembled section using 3x Bolts (1) and 2x Lanyards (2). Ensure bolts are securely fastened before use.



### WARNING

- Ensure assembly is carried out in the above order.
- Ensure that you have all parts required before assembly.
- Once the cover has been fitted the item cannot be easily dismantled.
- Whilst the clips will require moderate force to fasten them securely, do not apply excessive force as this may result in damage to the clip.
- Whilst the item is weather and frost resistant, to prolong the life of the product, site in a sheltered location. If using in sub-zero temperatures, take care to open and close the lid carefully so as not to cause stress to the hinges.

### PACKAGING DISPOSAL:

- Dispose of the packaging at your local recycling centre.
- Dispose of paper and carton separately from plastic bags at your local recycling centre.
- Dispose of the item at the end of its lifespan at your local authorised household waste recycling centre.

