

Read instructions carefully before use and retain for future reference.

HOW TO USE

- Plug into mains socket and switch on
- Open protective cover
- Press "RESET" button. Ensure that the LED indicator is now lit red.
- Press the "TEST" button. The LED indicator will no longer be lit.
- Press the "RESET" button again (once only) and close protective cover.

WARNING

- Check cable and unit for damage before use.
- Do NOT use if damaged.
- Ensure the work area is clear before use.
- Ensure that the cable is positioned carefully to avoid it becoming a trip hazard.
- Keep children and pets away from work area.
- Do NOT get wet.
- Do NOT exceed safe working load
- Do NOT hang the item by the power cable.
- If the RCD continually trips out, seek expert advice.
- Store in a cool, dry place.
- Should the fuse need to be replaced, only use BS1362 13 AMP rated fuse.
- Always switch off after use and remove the plug from the wall.

TECHNICAL INFORMATION

- 13A 240V ~ 50Hz
- Max load: 16A/3600W
- Rated trip current: 30mA
- Trip speed: <30mS

PACKAGING

- Dispose of the packaging at your local recycling centre.
- Dispose of paper and carton separately from plastic bags at your local recycling centre.
- Dispose of the item at the end of its lifespan at your local authorised household waste recycling centre.