Universal Socket Wrench 10054

Please read carefully before use and retain for future reference.

Instructions





Extension piece









Contents:

- 1 x Universal Socket
- 1 x Handle with ratchet function
- 1 x Extension piece

Instructions for use:

- Press in the bar on the back of the ratchet head and rotate anti-clockwise to set to tighten or clockwise to set to loosen.
- Place your Universal Socket around the screw head or nut.
- Your Universal Socket Wrench will self-adjust to accommodate different kinds of screw heads or wing nuts from 9mm-21mm.































Back of ratchet head

DISPOSAL

Dispose of all paper, cartons and plastic in accordance with your local recycling regulations. At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.

Head Office, 11 Bridge S

