


Please read these instructions fully before use and retain for future reference.

ASSEMBLY

- When unfolding the ladder, ensure that the safety locking clip underneath the top step is locked in position.
- To fold down, push down on the black lever to release the safety locking clip before folding.

WARNING


- Always ensure ladder is fully unfolded and hinges, footplates and safety locking clip are securely in position before use.
- Do **NOT** use if damaged in any way.
- Maximum weight load limit: 150kg (23st 8lb).
- Do **NOT** exceed maximum weight load limit. Only one person should mount the ladder at any time.
- Always take care when mounting and dismounting. Always mount and dismount facing towards the ladder.
- Always clear the work area of any hazards or obstacles before use, including overhead.
- Always wear suitable footwear when using the ladder.
- Do **NOT** lean from the ladder. Always re-site the ladder to a more suitable position.
- Only use on a firm, flat and level surface.
- Periodically check that all nuts and bolts are secure and joints are well lubricated.
- For domestic use only.
- Children should be kept away from the work area. Do **NOT** allow children to climb on the ladder.



Safety locking clip underneath the top step is locked in position



To fold down, push down on the black lever to release the safety locking clip before folding



COMPLIES WITH EN14183

PACKAGING

Dispose of the packaging at your local recycling centre.

Dispose of paper and carton separately from plastic bags at your local recycling centre.

Dispose of the item at the end of its lifespan at your local authorised household waste recycling centre.

Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

Coopers
OF STORTFORD

*Calls cost 7 pence per minute plus your telephone company's network access charge