

Included in this set:

1 x 24cm pan
1 x 24 cm fry pan
1 x 20cm pan
1x 18 cm pan
1 x 16 cm sauce pan
1 x 16 cm pan

Care & Use:

Wash before first use in warm, soapy water and dry thoroughly.

This product is not suitable for a dishwasher, hand wash only.

Dry thoroughly before storage.

To remove burnt on food, leave to soak for a few minutes in hot, soapy water before starting to clean.

Warning:

Never use heat above 230 C, 450F, Gas Mark 8.

Metal kitchen tools should not be used as they may damage surface of your pan.

Pans should be gripped using the intended handles only. Use heat protection gloves or similar to handle hot pan handles.

Do not cut or slice food whilst in the pan.

Do not use metal scourers or harsh abrasives as these could damage the surface of your pan.

Suitable for use on conventional ovens and induction hobs

Disposal:

Dispose of all paper, cartons and plastic in accordance with your local recycling regulations.

At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.



6pce Pan Set 10186

Care & Use

v001:24/09/15

Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU
Tel: 0844 482 4400
Fax: 01279 756595
www.coopersofstortford.co.uk

Coopers
OF STORTFORD