

All in One Chopper & Mandolin 10270

Instructions


Please read carefully before use and retain for future reference.

v001: 2/12/15

- Wash and dry thoroughly before first use.
- Wash in a mild detergent and dry with a soft, clean cloth. Ensure all metal parts are dried adequately or premature rusting may occur.
- Dishwasher safe.
- You Chopper and Mandolin has a soft grip and provides non-slip protection.

CAUTION

The blades are extremely sharp, handle with care and keep out of reach of children.



This set includes:

- 1 Fine grater
- 2 Coarse Julienne grater
- 3 Grater
- 4 Slicer
- 5 Fine Julienne grater
- 6 Chopper
- 7 Fine chopper
- 8 Food box unit
- 9 Round food guide (pictured in final image)
- 10 Cutting top
- 11 Small cleaning tool

Coopers
OF STORTFORD


How to use:

TO USE CHOPPER/DICER:

- Place the item to be cut in the centre of the cutting blade with a flat side facing down.
- Press down with 2 hands on the surface to chop or slice
- Align cleaning tool with grooves on chopper lid to clean excess food off.

Assembly of cutting top:

- To install the cutting top, push the two buttons inward to draw back the pivots and slide the cutting top in from underneath.
- Release buttons to lock in cutting top.
- Push the two buttons inwards to release chop pusher from main unit as shown in images.



TO USE MANDOLIN LID:

- Remove chop base from the bowl and place Mandolin lid on serving bowl.
- Insert desired blade into blade holder.
- Press down to fix the blade and remove the blade by pressing underneath with 2 thumbs.
- Lock the food holder on the main unit by pressing the locks on both sides.
- Use the food guide to push food down and hold it in place.
- Slice food easily and safely by pressing down the food guide and sliding the food holder.



Disposal

- Dispose of all paper, cartons and plastic in accordance with your local recycling regulations. At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.



Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756595
www.coopersofstortford.co.uk

Coopers
OF STORTFORD

*Calls cost 7 pence per minute plus your telephone company's network access charge.