



TECHNICAL DETAILS: Low Voltage Item
Uses 5x AAA batteries (not included)

USER INSTRUCTIONS:

The 6 bright white LEDs activate automatically when the motion sensor detects movement and will stay illuminated for 20 seconds with a single detection.


The adhesive backing and screws mounting options allow you to place the lights anywhere and the streamlined design makes them ideal for use within cupboards and drawers.



1. Push out the battery cover as direction of the arrow



2. Put the five PCS AAA battery into the battery box by the right positive and negative direction.



3. Tear the strong double-sided adhesive, then stick it to the place you want. Or use the screws to fix it.



4. Push the battery cover to the right direction of two parts as the picture shows.

CLEANING INSTRUCTIONS:

Not waterproof.

Remove batteries. Clean with a damp cloth, dry and then re-insert the batteries.

BATTERIES

- Keep batteries away from children and pets.
- Fit batteries noting their +ve and -ve polarity symbols when inserting into the battery compartment.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal: spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.
- Always observe the correct polarity when inserting batteries.
- Do not mix old and new batteries.
- When performance becomes reduced, replace the batteries.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

