OVER SOFA TABLE 10497


Instructions for Use

Please read and retain these instructions for future reference

v001: 31/08/16



PARTS:



- A. Top board x 1
- B. Back board x 1
- C. Small side board x 2 (C-1, C-2)
- D. Bottom board x 1
- E. Side board of magazine rack x 2 (E-1, E-2)
- F. Horizontal bar x 3
- 1. Bolts x 3
- 2. Nuts x 3
- 3. Screws x 12
- 4. Pads x 4
- 5. Plastic caps x 8




Please read and retain these instructions for future reference

v001: 31/08/16

Assemble:


1. Set the Top board (A) upside down on a clean, soft surface. Secure 3 bolts (1) into the holes in the Top (A).



3. Assemble two small side boards (C) and tighten bolts by nut (2).



5. Use 2 screws (3) to tighten the Bottom board (D) to Side board (B) and add 4 Pads (4) on 4 corners.




2. Insert the back board (B) and tighten the bolt by nut (2) inside of it.



4. Use 4 screws (3) to secure back board (B) to two side board (C).









OVER SOFA TABLE 10497

Instructions for Use

Please read and retain these instructions for future reference

v001: 31/08/16

7. Insert 3 horizontal bar (F) to one end of side board (E-1).



** The placement of screws (3) on 2 side boards of magazine rack.



8. Put another side board of magazine rack (E-2) and using screws (3) to tighten it from side and bottom.



** Cover the plastic caps (5) on all screws holes.



WARNINGS / CAUTIONS:

Adult Assembly Required

Do not place directly in front of or near sources of heat

Periodically check that all fixings are secure and tighten if necessary.

Weight limit: 6 kgs

CLEANING INSTRUCTIONS:

Clean with a dry cloth or duster.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.

