



## Parts

1. 15m flat hose with easy wind storage reel
2. 7 pattern spray gun

Before you begin using this set, unwind the flat hose completely.

## Connecting Hose

To use the hose first time screw the tap connector to the tap – if necessary screw the correct reducer into the tap connector. Hand tighten to secure.

Snap on the connector (3) attached to the end of the hose onto the tap.

## Using the Spray Gun

Snap on the spray gun to the end of the hose.

Select the setting by twisting the ring dial on the spray gun to choose a suitable pattern from MIST, JET, SHOWER, FLAT, CENTER, CONE and FULL.

You are now ready to begin spraying.

To use the locking trigger mechanism, pull back the trigger and swivel the lock backwards.

## After Use

Turn off tap and disconnect the hose.

Remove spray gun.

Click tap connector (3) in place and wind hose onto reel.

## DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.