Shoe & Umbrella Rack 10575

Instructions for Use

Please read and retain these instructions for future reference

v001: 07/10/16



PARTS:



- A. Side panel x 1
- B. Middle panel x 1
- C. Side panel x 1
- D. Shelf x 4
- E. Wood slatted board x 1
- F. Small bar x 2
- G. Large bar x 2
- H. Wood plug x 8
- Screws x 24
- J. Wood caps x 24

Tools required: Crosshead screwdriver (not provided)

Shoe & Umbrella Rack 10575

Instructions for Use


Please read and retain these instructions for future reference

v001: 07/10/16

Assembly Instructions:


STEP 1

Use the Screws (I) to attach each Shelf (D) to the Side panel (A)



STEP 2

Use the Screws (I) to attach the Middle panel (B) to attach shelf (D)



STEP 3

Insert the Wood plug (H) into the screw holes on Middle panel (B)



STEP 4

Attach one side of Small bar (F) to top of Middle panel (B) and use screws (I) to tighten. Insert a Wood plug (H) on another side of Small bar (F). Repeat for the Large bar (G) and slide in the Wood slatted board (E) between the Large bar (G)



Shoe & Umbrella Rack 10575

Instructions for Use

Please read and retain these instructions for future reference

v001: 07/10/16

STEP 5

Attach the Side panel (C) to 2 Small bars (F) and 2 Large bars (G)



STEP 6

Use Screws (I) to tighten the Side panel (C) Add the wood caps (J) on all screws holes.



WARNINGS / CAUTIONS:

Adult Assembly Required

Do not place directly in front of or near sources of heat

Periodically check that all fixings are secure and tighten if necessary.

Use on a level, stable surface

Weight limit: maximum 8Kgs per shelf.

Tools required: Cross-head screwdriver (not provided)

CLEANING INSTRUCTIONS:

Clean with a dry cloth or duster.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.