




Turn screw anti-clockwise to open clamp.



Attach handle to tool handle or pole, turn screw clockwise to tighten clamp.



Undo screw to adjust handle to desired position.



DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.