

24cm Die Cast Low Casserole Pot w/Lid 10617 Instructions for Use

Please read and retain these instructions for future reference


v001: 24/10/16



Die cast 24cm low casserole with lid

Detail: \varnothing 24 x 7.5cm/Body thickness: 2mm/Bottom thickness: 4.5mm approx..
3 layer marble coating inside, marble coating outside, soft touch handle


- Heavy gauge aluminium body.
- Ceramic non-stick coating.
- Bonded steel base for use with induction hobs.
- Soft touch stay cool silicone coated handles
- Tempered glass lid with steam vent.
- Suitable for all hobs including induction.



INDUCTION



GAS



ELECTRIC CERAMIC



HALOGEN

CARE AND USE

- Wash thoroughly before first use.
- Do not use in the oven.
- From time to time, the handle/s on your cookware may need tightening, this can be carried out with a standard cross-head screwdriver (do not over tighten).
- Use of oven gloves is recommended when handling hot dishes.

CLEANING INSTRUCTIONS

- Dishwasher safe. We do recommend hand wash for prolonged lifespan of any product.
- Do not allow any excess liquid to dry in the handle bowl or within the valve.
- Pour a small amount of detergent into the bowl allowing it to disperse.
- Run under a lukewarm tap until clear of detergent and fully cleaned.
- Stand lid on its side to allow drainage of excess water, hand dry immediately after.
- Do not use metal tools or scouring pads.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.

Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756595
www.coopersofstortford.co.uk

Coopers
OF STORTFORD

*Calls cost 7 pence per minute plus your telephone company's network access charge.