Spin Mop 10629/F060 PU/F060 GR

Instructions for Use

Please read and retain these instructions for future reference

v003: 29/10/20



Rotating washable mop with telescopic handle Telescopic rod 120cm ; Spinner 46.5 x21 x26.5cm

ASSEMBLY INSTRUCTIONS:



Plastic handle with hanging loop.



Insert stainless steel joint into rotating sleeve, rotate anti-clockwise to complete assembly.



Rotating sleeve. Move sleeve to the left to lock. To release move sleeve to the

Head Office, 11 Bridge Street Bishop's Stortford CM23 2JL Tel: 0844 482 4400 Fax: 01279 75659 www.coopersofstortford.co.ul



Spin Mop 10629/F060 PU/F060 GR

Instructions for Use

v003: 29/10/20

Please read and retain these instructions for future reference

right.

To use

- After assembling all parts of the mop pole, hold the mop upright, position mop in the bucket's water reservoir to sit in the groove in the middle to lock it.
- Fill the bucket with water and your choice of cleaning fluid if required. Keep water level slightly below the bottom of the bucket spinner.
- Do not overfill as the spinner will not work properly.
- Push handle down to swish the mop head in the water to saturate.
- Insert the mop in the grooves of the bucket spinner ensuring all the fabric is tucked inside.
- Push down on the handle to spin the mop until you feel it is dry enough to clean the floor.

Warnings

- Ensure the bucket is on a level surface.
- This is not a toy, keep away from children.
- Not for commercial use.

Maintenance

- To remove micro fibre mop head pull it out hard from the plastic ring in the middle. It is fixed securely so you may need to pull hard. The mop head can be hand washed as required.
- Always wipe clean and dry the bucket with a soft cloth after use.
- Air dry the micro fibre mop head before storage.
- Store all parts in a frost-free place.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – Contains the following recyclable plastic.

Code & Symbol	253 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)



Spin Mop 10629/F060 PU/F060 GR

Instructions for Use

Please read and retain these instructions for future reference

v003: 29/10/20

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

Head Office, 11 Bridge Street, Bishop's Stortford CM23 ZJU Tel: 0844 482 4400* Fax: 01279 756595 www.coopersofstortford.co.uk

ORTFORD