



USER INSTRUCTIONS:

Number and type of batteries required:
3xAAA batteries not included.

The Flashlight folds down to a handheld torch or unfolds to a strip light which can be hung up on the hook in the back of the Flashlight.

The On/Off button switches to turn on either light.

CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do not shine light directly towards eyes.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.

BATTERIES:

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Ensure batteries are connected in accordance with +ve and -ve connections.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

