


Suitable for smooth floor surfaces such as wooden, tiled, parquet flooring and carpet tiles.

Assembling the handle:

1. Remove the body and the 3 handle parts from the carton.
2. Take handle grip Part (D) and slide over handle Part (A).
3. Take Part (B) and screw into Part (A).
4. Take Part (C) and screw into Part (B).



Connect handle to body:

Take the fully assembled handle and push into the body of unit Part (E) until tight.



How to operate the Sweeper:

Holding the handle firmly, push down gently to drive the sweeper FORWARD to pick up debris.

The sweeper is designed to be used in a forward motion (in all directions), as indicated on the body of the sweeper.



How to empty the Sweeper:


To empty debris, hold the sweeper over a dustbin. Locate the disposal door in the back of the sweeper.

Lift the door and empty the debris.
The capacity of the dirt tray is 350ml.



CARE AND CLEANING INSTRUCTIONS:

To keep your sweeper working smoothly, use a brush (not included) to clean the centre (long) brush and both round brushes. The brushes can also be unscrewed for cleaning.



DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.

Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU

Tel: 0844 482 4400*

Fax: 01279 756 595

www.coopersofstortford.co.uk

Coopers
OF STORTFORD

*Calls cost 7 pence per minute plus your
telephone company's network access charge