

**BATTERY OPERATED BRONZE FINISHED OUTDOOR CLOCK.****THERMOMETER:**

The thermometer is designed as a guide to measuring the temperature to within +/- 3° C.

The thermometer may need to be re-calibrated after transit.

This is simply carried out by:

- Hold the coil movement casing at the rear of the thermometer firmly.
- Then slowly twist it in an anti-clockwise direction to read a higher temperature and clockwise direction to read a lower temperature.

Temperature readings should only be taken when the thermometer is in the shade.

CLOCK:

The hands on the clock may come loose from their spindle fixing during transit.

This is a design feature to protect the mechanism from damage in transit.

Firstly push the hour hand back into its spindle, followed by the minute hand.

Once the hands have been pushed back into place they should be manually positioned to read 12 o'clock before following the next steps.

1. Remove the rear battery compartment cover by gently pulling it away from the casing.
2. Insert 1x1.5v AA battery (not included) into the battery compartment, noting the polarity.
3. Adjust the time by turning the wheel on the movement in the required direction until the current time is displayed.
4. Refit the rear battery cover.

FIXING AND LOCATION INSTRUCTIONS:

Locate the clock thermometer so that it is out of direct heat and sunlight.

Fix to a wall using suitable wall plugs and screws (not included) by means of the bracket at the rear of the casing. Ensure this is secure and firmly held in place.

CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

BATTERIES:

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal: spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL:

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

