
Please read and retain these instructions for future reference

v001: 27/11/17



INSTALLING AND CHANGING BATTERY:

- Insert one new AA battery (not included) into the battery compartment (A) on the back of the clock movement piece according to the polarity symbols indicated in the battery compartment.
- 2. Set time by turning dial (B) on the movement. Set day by turning dial (C) on the movement.
- 3. Replace battery twice a year even if clock is still running.



BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Keep batteries away from children and pets.
- Battery disposal: spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.



