# Instructions for Use

Please read and retain these instructions for future reference

v001: 19/12/17



## **PACKAGE INCLUDES:**

1 x Mini USB fan 1 x 18650 Lithium Rechargeable Battery Li-ion 18650-3.7V(2000mA) included 1 x USB Cable

#### **INSTRUCTIONS FOR USE:**

## **SPECIFICATIONS:**

Speed mode: 3 ranges

Battery specification: 18650 Li-ion 3.7V (2000mA)

Output power (max.): 5W

Dimension: 11cm x4.7cm x1.5cm

Working time: 3 - 8hrs
Charging time: 2 - 3hrs
Net weight (including battery): 184g

#### **OPERATION INSTRUCTION:**

- Green button (ON): press once to turn on and press again to adjust fan speed.
   Sequence: Power on Low Medium High Power off. Press and hold for 2 seconds to activate the LED flashlight.
- 2. Red button: Press and hold for 2 seconds to turn off the unit.
- 3. Charging light indicator: red colour when battery is charging, green colour when fully charged.
- 4. Charge the battery through the micro USB input to a computer or laptop.

#### **WARNINGS:**

- Do not put your fingers or any other objects into the fan blade when the unit is turned "ON".
- Lithium-ion battery included does not have any memory retention function on charging level status of the battery so you may charge it at any time without the need of discharging the battery prior to charging. Recharge the battery whenever possible to properly maintain it and extend its life.
- Fully charge the battery and remove it from the fan whenever you are not going to use the fan for a certain period of time. Store the battery in a cool place.
- Avoid running the battery when ambient temperature exceeds 60 °C and do not dismantle or damage the battery casing to avoid serious injuries or damage to the battery.
- Only use the originally supplied battery and accessories to ensure the proper performance and service life of the product.



Please read and retain these instructions for future reference

v001: 19/12/17

#### **CARE AND CLEANING INSTRUCTIONS:**

- Always switch off and remove batteries when not in use.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

### **BATTERIES:**

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

#### **DISPOSAL**

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.



