



INSTRUCTIONS FOR USE:

- Sharpens knife blades in seconds.
- Two independent spring-action arms
- Ultra-hard tungsten carbide flexes and contours to the blade
- Suitable for standard, serrated, and bevelled blades
- Sharpens, hones, and polishes knives
- Small, compact design is easy to store
- Easy to use

This side facing you:




Gently hold the sharpener as shown to keep it stable. Keep fingers/hands away from knives when sharpening.

Coarse sharpening

Hold the knife tip **DOWN**

Pull knife towards you.

Use this action to sharpen all very dull or damaged blades.




Fine sharpening

Hold knife tip UP.

Pull knife towards you.

Use this action for honing or daily maintenance. No metal will be removed.



Polishing

Hold knife level.

Pull knife towards you.

Use this action to make the blades razor sharp.



CARE AND CLEANING INSTRUCTIONS:

- Always wash the knife after sharpening and before use.
- Clean the sharpener with a damp soft cloth.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.