

Set 5 Cut Out Solar Stake Lights

K744 v001: 23/02/22

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

(H) 18 x (W) 5.8 x (D) 5.8 cm (LEDs not replaceable)

- WARM WHITE LED
- LIGHTS CREATE A STUNNING SILHOUETTE EFFECT
- PERFECT FOR LIGHTING PATHS, FLOWER BEDS OR BORDERS
- AUTOMATICALLY LIGHTS UP AT DUSK
- UNIQUE CARVED DESIGN THAT ADDS BEAUTIFUL REFLECTIONS ON THE GROUND
- WEATHER RESISTANT
- EASY TO INSTALL
- ADDS DEPTH AND ATMOSPHERE TO YOUR GARDEN

Battery 1x AAA 1.2v 200Mah, Ni-MH, Rechargeable

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

CHARGING AND OPERATION:

1. There is an "on/off" switch at the solar panel case. Take out the solar panel box on the top of the light and find the switch and push the switch to "on" position. Then replace the cover and position the light in a sunny location. Charge the solar product by placing it under direct sunlight for **at least 8 hours**.
2. The light will work automatically. It will charge under direct sunlight during the daytime and illuminate at night.

NOTE: In order to test the lights simply cover the solar panel with your hand and the light should turn on automatically.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically.

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.

Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.

Battery replacement:

If solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1x AAA 1.2v 200Mah, Ni-MH, Rechargeable – Same equivalent type as recommended must be used).

Step1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included) .

Step2: Remove the exhausted battery and install 1x new AAA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.

Step3: Replace battery compartment cover, screw it back into position and make sure is properly sealed.

Step4: Charge the solar product by placing it under direct sunlight for **at least 8 hours**.


BATTERIES

- Keep batteries away from children and pets.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer’s safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product’s lifespan please check with your local council authorised household waste recycling centre for disposal.

