

Solar Light Up Windmill

K215 v002: 10/11/21

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

(H) 50 x (W) 42 x (D) 17.5cm


- POLYCRYSTAL SILICON SOLAR PANEL
- 5 WARM WHITE LIGHTS

Battery: 1 X 1.2V AA 600mAh NI-MH Rechargeable

LEDs not replaceable

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.



*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

Before using first time

Allow lamp to charge for at least 8 hours in full sunlight with the ON/OFF switch in the ON position. The ON/OFF switch is located under the solar panel. Once the batteries are fully charged, set the ON/OFF switch to ON. If the lamp does not turn on after dark refer to Maintenance section.


Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

Please note that the battery does not operate the windmill sails, these will only rotate with wind power.

First time use

There is a button on the battery compartment (located on the Top of the light). Press the button into the "ON" position to start the automatic system.



When the environment turns dark, the solar light will automatically illuminate. The light will only work if there is enough power stored in the battery.

Precautions


1. Please note, the light is designed to activate when there is little ambient light. If there are strong light sources nearby, the LED light may be very dim or not work at all.
2. Although the battery has been charged by the manufacturer, the electricity level may have declined by the time you receive it. Please charge it for a full day to realize maximum performance.
3. Surface of the solar panel must be kept clean. If it is obscured it will influence the efficiency of charging.

Troubleshooting

If the light does not work please check the following:

1. Make sure the power switch is in the "ON" position.

2. Check the battery to make sure that it has secure contact with the terminals.
3. Ensure that the solar light is placed in a sunny location and not in a shady area. The solar panel faces towards the sun.



Replacing Battery

If the light stops working after it has been used for a long time (about 18 months), the battery may be beyond its lifespan. Please open the cover of the battery compartment to replace the rechargeable battery.

Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. During the winter if you can bring it inside and give a good clean ready for next year.

BATTERIES


- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.

- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	Polyresin
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

