

**WARNING**

To reduce the risk of injury when using this mower lift it is recommended to always follow basic safety precautions.

Read these instructions before using this product and save these instructions for future reference.

**ATTENTION**

Before lifting any load, make sure you know how to use this tool. Incorrect use of this mower lift can cause serious injury. Any other use other than that specified in this manual may result in damage to the mower lift and represent a serious danger to the user.

**SAFETY INSTRUCTIONS**

Use the mower lift only for lifting operations.



- Do not allow children to use or play with the mower lift.
- Never allow other people or children to sit on the load when using the mower lift.
- Never leave the mower lift unattended when it is in use.
- The mower lift is designed for use on flat and stable surfaces. Use on a soft or uneven surface may cause instability of the mower lift and cause the mower to fall.
- Check the mower lift before each use for any sign of damage. Do not use if there is any evidence of corrosion.
- The appliance should not be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

**TECHNICAL**

This mower lift will support a sit-on mower that does not exceed 400kg at a maximum tilt of 60°.

**ASSEMBLY**

- Position the mower jack on a level and stable surface.
- Remove the locking pin (3).
- Raise the vertical lead screw (2) and ensure the lugs on the nut face left to right.



- Replace the locking pin (3) in front of the lead screw (2).
- Turn the handle clockwise to raise the mower and turn anti-clockwise the lower the mower.

## OPERATION

- Assemble lift as per assembly instructions.
- Position the mower lift on a flat level surface.
- Locate the sit-on mower so the front or rear wheels fit between the lifting bars (5).
- TIP. Ensure the fuel tank is no more than 25% full to avoid fuel spillage.
- Turn the handle (6) clockwise to raise the mower 2 to 3cm to ensure the right amount of balance is achieved before continuing to lift. If the mower is unbalanced turn the handle anti-clockwise to return the mower to the ground. Reposition the mower in between the lifting bars and repeat the process.
- It is recommended that you position one or two jack stands to support the lawn mower lift fail when in use.

