# Pk2 LED Magnifying Glass н631

## Instructions for Use

Please read and retain these instructions for future reference

v001:10/02/21



### Dimensions

(H)11.3cm x(W24.2cm x(D)3cm

### Composition

ABS Housing, glass lens


3X LENS JUMBO SIZE ILLUMINATED READING MAGNIFIER POWERED BY 2X AA BATTERY (NOT INCLUDED)

### **ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:**

Unpack the components carefully. Please check all parts have been removed from the packaging.

### **Battery installation**

Slide the battery cover at the end of the handle and remove the battery cover. Install 2 xAA new batteries observing correct polarity. Reinstall the battery cover in the reverse order of removing the battery cover.



#### **User Instructions**

To control the COB light press the ON/OFF button on the side of the product.



## Pk2 LED Magnifying Glass н631

### Instructions for Use

Please read and retain these instructions for future reference

v001:10/02/21

### Warnings

- Do not use for other than the intended purposes.
- Do not point the magnifier directly at the sun or bright light source, etc.
- Do not use for long periods to avoid eye strain.
- Protect from scratches.
- If not in use, please keep magnifier in a dark place.
- Do not place magnifying glass near a heat source of fire. The product may be deformed or damaged.
- Do not disassemble or modify this product.
- Do not drop.
- Keep out of reach of children.

### **CARE AND CLEANING INSTRUCTIONS:**

Wipe with a clean dry soft cloth.

#### **BATTERIES**

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

### **DISPOSAL**

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

