## Compact Dehumidifier

J024

# Instructions for Use

Please read and retain these instructions for future reference

v002:03/10/22

### Features

The Compact Dehumidifier uses Peltier technology (no compressor), which makes it light and quiet. It is perfect for small rooms. Poor ventilation causes musty odours and fungus in wardrobes, larders, cabinets or storage rooms etc. The Compact Dehumidifier eliminates this problem by keeping them free of unwanted moisture.

- To avoid electric shock. Do not open. There are no user serviceable parts inside.
- Any repair work must be done by a qualified technician.
- Specifications are subject to change for improvement without prior notice.

### Specifications

Capacity: approximately 200ml – 250ml per day at 30°C, 80% RH Cooling element: thermos-electric Peltier module Fan: 80mm x80mm DC Brushless motor Power adaptor: DC 9V 2.5Amp Power consumption: 21W Removable water tank: 500ml Water Level Detector: Automatic switch

off with "Yellow" LED Indicator when water tank is full.


Product dimension: 155mm (W) x 220mm

(H) x 1300mm (D)

COOPERS

**OF STORTFORD** 

Working environment: Over 15°C, over 40% RH (relative humidity)



### Connections

- 1. After removing the packaging materials, there should be 2 items:
  - a. Compact Dehumidifier.
  - b. AC/DC Power adaptor.
- 2. Plug the DC power jack of AC/DC power adaptor to the DC power socket, then connect the AC plug of the AC/DC power adaptor to the appropriate main socket.
- 3. Press the "On/Off" button to "On" position, the Compact Dehumidifier will begin to operate. The green LED will turn on. Listen and feel for the air blowing from dry air outlet.
- 4. To switch off unit, press "On/Off" button to "Off" position, the Compact Dehumidifier will be turned off.

### **Removable Water tank**

When the water tank is full, with approximately 500ml of water collected, the unit will switch off automatically and the "Yellow" LED will be on.

To remove the water tank, first switch off the Compact Dehumidifier, press "On/Off" button to the "Off" position. Then, remove the water tank from the unit and put the water tank back into the unit. To continue dehumidifying press the "On/Off" button to "On" position again.

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400\*, Fax: 01279 756595 <u>www.coopersofstortford.co.uk</u> EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269 \*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

## Compact Dehumidifier J024

## Instructions for Use

Please read and retain these instructions for future reference


v002:03/10/22

#### Cleaning

Before cleaning the unit, turn off the Compact Dehumidifier and unplug the AC plug from the main socket first. Use a piece of soft cloth to clean the surface of the product or use a brush to wipe the dust off the grills of the air inlet. Do not immerse in water, keep dry at all times.

#### Cautions

- Switch the unit off by pressing the "On/Off" button to "Off" position.
- Avoid using the AC/DC power adaptor in wet or damp place, and position it in areas where the air ventilation is good.
- 3. Keep the front grill and top outlet free from air blocking materials such as clothing, plastic bags or papers.
- 4. Do NOT place on delicate surfaces that are susceptible to heat or moisture damage.
- Always keep the unit in an upright position to avoid water leakage.
- 6. This is not a toy keep away from children.
- 7. Not for commercial use.





AC/DC power adaptor

#### **PLUG WIRING (UK & IRELAND)**

This appliance is supplied with a mains adaptor/charger with BS1363 plug pins.

**DO NOT** use If the socket outlets in your home or office are not suitable for this product's mains adaptor/ charger plug pins. Attempts to insert the mains adaptor/charger into the wrong socket is likely to cause electric hazard or damage.

**DO NOT** use with any other mains transformer/charger than the one that is supplied with this product.

#### DISPOSAL

• Coopers of Stortford use recyclable or recycled packaging where possible.



COOPERS<br/>OF STORTFORDUK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU<br/>Tel: 0844 4824400\*, Fax: 01279 756595<br/>www.coopersofstortford.co.uk<br/>EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France<br/>Tel: (+44) 1279 701269<br/>\*UK Calls cost around 7 pence per minute plus your telephone company's network access.<br/>Please check with your telephone supplier.

J024

## Instructions for Use

Please read and retain these instructions for future reference

- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags this is made from the following recyclable plastic.

Code & Symbol	OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



