




Welcome Globe Solar Light

- **Light Source:** 6x2835 SMD, 120 Lumens
- **Solar panel:** 5V 200mah monocrystalline
- **Battery:** 1x18650 3.7V 1200 mah Li-on(included)
- **Material:** ABS and glass
- **Size:** 21cm x15cm x19.7cm
- With switch at the bottom
- With light sensor and PIR motion sensor
- **Mode:** low lighting when no motion detected, 100% lighting when motion detected, after 30 seconds turn to low lighting cycle
- **Sensing angle:** 120° Sensitive time: 3s
- **Sensitive distance:** 3-5m
- **Charging time:** around 8-10 hours
- **Working time:** 80-100 times under 30s sensor mode
- IP44

Mounting the Welcome Globe Solar Light (Wall fixings included)



Charging and use

Charge the solar light by placing it in direct sunlight for 8-10 hours before use. Once charged, the solar light will automatically turn on when it gets dark and turn off in daylight or when it loses charge.

IMPORTANT:

1. Install the solar light in an area that has 8-10 hours of direct sunlight per day.
2. Select a location that is away from other light sources at night, such as street lights, as this can cause the solar light to not turn on.
3. The duration of light depends on the solar light's level of sunshine exposure which can be affected by geographical locations, weather conditions, and hours of daylight.

Replacing the battery

If the light stops working after it has been used for a long time (approx.18 months), the battery may be beyond its lifespan. Open the cover of the battery undoing the screws with a screwdriver to replace the old one with a new rechargeable battery. Battery specification: 3.7V, 1x1200 mah, rechargeable Li-polymer battery. The LED lamp is not replaceable.

Precautions

Please note that the light is designed to work once it is dark. If there are strong light sources nearby, the lamp might be very dim or not functioning at all. Although the manufacturer has charged the battery, the

Welcome Globe Solar Light F898 Instructions for Use

Please read and retain these instructions for future reference

v001: 27/03/19

electrical levels will have dropped when you receive it. Please charge it for a full day to optimise performance. The surface of the solar light must be kept clean to efficiently charge the battery.

Activating the Motion Sensor

The Welcome Globe Solar Light only works during the hours of darkness. When the sensor detects movement, the LED light will turn on and remain on for two minutes. In daylight, the solar light will remain off to conserve battery life.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.



*Calls cost 7 pence per minute plus your telephone company's network access charge

Head Office, 11 Bridge Street,
Bishop's Stortford CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

Coopers
OF STORTFORD