
Please read and retain these instructions for future reference

v001: 23/03/20

Always position in direct sunlight.



Dimensions 135cm high

Battery

1x AA 1.2v 800Mah, Ni-MH, Rechargeable

- THIS WILLOW TREE HAS 20 BRANCHES AND EACH BRANCH HAS 10 LEDS ON SO AT NIGHT TIME IT REALLY COMES TO LIFE WITH ITS 200 LEDS CREATING A MAGICAL SHOW AT NIGHT
- TRAILING BRANCHES LOOK LIKE A WEEPING WILLOW
- STAKES SECURELY INTO THE GROUND
- COMES WITH A SOLAR PANEL THAT CHARGES DURING THE DAY AND COMES ON AUTOMATICALLY AT NIGHT
- YOU CAN CHOOSE BETWEEN HAVING THE LIGHTS ON STEADY OR FLASHING

BEFORE FIRST USE: Remove the protective film from the solar panel.

Stake

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.

CHARGING AND OPERATION:

- 1. Set switch (located on the back of solar case) to <u>"S (steady on)" OR "F (flash)"</u> position. Charge the solar product by placing it <u>under direct sunlight for at least 8 hours</u>.
- 2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to test the lights simply cover the solar panel with your hand and the light should turn on automatically.

IMPORTANT:

- 1. Install the solar product in an area where it can get direct sunlight.
- 2. Leave the switch to "S" OR "F" position.
- 3. Select an outdoor location away from other light sources at night, such as street lights. It may cause the product not to turn on automatically at night.
- 4. Duration of light depends on solar product's level of sunlight exposure, geographical locations, weather conditions and the hours of daylight.




Please read and retain these instructions for future reference

v001: 23/03/20


MAINTENANCE AND TROUBLESHOOTING:


- 1. Make sure the switch is set to <u>"S" OR "F"</u> position.
- 2. Keep the solar panel clean.
- If solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable battery as it may be weak or worn out. (Battery 1 pc "AA" 1.2v 800Mah, Ni-MH, Rechargeable – Same equivalent type as recommended must be used).



Step1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included). Step2: Remove the exhausted battery and install 1x new AA rechargeable battery according to the +/-polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.

Step3: Replace battery compartment cover, screw it back into position and make sure is properly sealed.





CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do NOT immerse in water.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

• Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.



Plastic recycling: PVC Polyvinyl Chloride





Solar Willow Tree

G498

Instructions for Use

Please read and retain these instructions for future reference

v001: 23/03/20

 At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.