G552

Instructions for Use

Please read and retain these instructions for future reference

v001: 28/02/20



Dimensions:

46cm x18cm

Composition:

Net: Wire mesh, aluminium mesh

Plastic (PS)

Rated voltage: 3V Output voltage: 1500V This product is not toy. Please keep out of the reach of children. This product emits an electrical shock

- THIS ELECTRONIC BUG ZAPPER BAT KILLS ANNOYING FLYING INSECTS INSTANTLY THANKS TO IT HIGH VOLTAGE GRID
- JUST HOLD DOWN THE BUTTON AND ZAP AWAY
- USE INDOORS OR OUTDOORS
- BATTERY OPERATED USING 2 X AA BATTERIES (NOT INCLUDED)

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

- Install 2 x AA batteries (not included).
- Grip the handle, press and hold the power button to activate.
- Swipe bugs with the wire section of the zapper.
- Dead bugs can be shaken or brushed off the zapper.

WARNING:

- Do not squeeze the wire section of the zapper to avoid electric shocks.
- Do not use near flammable substances.
- Do not wash the zapper with water.
- This is an electrical item and it should be respected as such.
- It must only be used to zap bugs. Never zap humans or pets.
- The wire mesh may hold a charge for a short while after the power button has been de-activated.

CARE AND CLEANING INSTRUCTIONS:

- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.



Insect Zapper Bat

G552

Instructions for Use

Please read and retain these instructions for future reference

v001: 28/02/20

DISPOSAL

• Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.



- This is made from the following plastic.
- 's (Polystyrene).
- At the end of the product's lifespan please dispose of it at an authorised household WEEE waste recycling centre.

