

ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions:

19.5 x9.5 x34cm

- FIX TO FENCES, BY THE SIDE OF YOUR DOOR, SHED ETC
- AT DUSK IT AUTOMATICALLY ILLUMINATES
- CHOOSE BETWEEN EITHER THE AMBIENT FLAME EFFECT LIGHT USING 34 YELLOW FLICKERING FLAME EFFECT LEDs (not replaceable) OR WHITE LIGHT USING 5 LEDs
- POWERED BY 1.2V AA 400MAH NI-MH BATTERY INCLUDED
- DISCREET SOLAR PANEL ON THE TOP OF THE LIGHT FOR OPTIMUM SUN ABSORPTION
- WALL FIXINGS INCLUDED

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

Operation

1. Push the W/OFF/C switch to the "W or C" position to activate the device.
2. Charge in direct sunlight for 6-8 hours.
3. The LED will turn on automatically at night. "W" position means the product will turn to white light, "C" position means the product will turn to flame effect.
4. Push the W/OFF/C switch to the "OFF" position to deactivate the device.

Replacing the Batteries

If the light stops working after it has been used for a long time (approx. 12 months), the battery may be beyond its lifespan. You may open the cover to change to a new rechargeable battery. Battery specification: 1.2V 400mAh Ni-MH battery.

Care and Maintenance Recommendations


1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. During the winter if you can bring it inside and give a good clean ready for next year.

Battery replacement:

Step1: Unscrew the battery compartment cover by using a Phillips head screwdriver (not included).


Step2: Remove the exhausted battery and install 1x new AA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.

Step3: Replace battery compartment cover, screw it back into position and make sure is properly sealed.



Care and Maintenance Recommendations

4. Clean solar panel with a soft sponge every couple of weeks.
5. Make sure all connectors are still tight and no water getting in.
6. During the winter if you can bring it inside and give a good clean ready for next year.




BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups

Notes
Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

