

Solar Cascading Watering Can

H309 v01: 13/11/20

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT FOR BEST CHARGING.



Dimensions:

22.5 *9 *92cm (incl. stake)

- **PRETTY BRONZE CUT OUT WATERING CAN STAKE**
- **WARM WHITE LEDS (not replaceable) LIGHT UP THE CENTRE OF THE WATERING CAN CREATING A PRETTY LIGHT PATTERN, THEN A SEA OF FAIRY LIGHTS POUR OUT OF IT LIKE A MAGICAL WATERFALL**
- **SPARKLES IN THE DAY LIGHT THEN ILLUMINATES IN ALL ITS GLORY AT NIGHT TIME**
- **SOLAR POWERED**
- **THE WATERING CAN HANGS OFF OF A BRONZE SHEPHERDS CROOK STAKE**

Batteries: 1*AA 1.2V NI-MH 300MAH rechargeable battery, replaceable

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. **DO NOT** push directly against the solar cell or the ornament housing containing the actual LED light.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

User Instructions

- Hang watering can over the stake's hook.
- Slot watering can handle into stake

Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. During the winter if you can bring it inside and give a good clean ready for next year.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Install batteries in accordance with its polarity symbols.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Keep batteries away from children and pets.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 PP
Type of Plastic	Polypropylene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

